

“HXR-NX3” and “HXR-NX3/1” System software update

Windows

Mac


2017/4/4

Update “HXR-NX3” and “HXR-NX3/1” system software

Confirming if the unit is applicable (Version Check)

Select [Menu] → [OTHERS] → [VERSION DISPLAY] on the camera.

The system software version is displayed. Check if “BODY” version is “Ver.1.00” ~ “Ver.2.00”.



Current version Ver.1.00/1.01/1.02/1.03/2.00
is a target version.

Preparing system software update

Please prepare the following items in addition to your camera.

System requirements for a computer

【 Windows 】

[Supported OS]

Windows® 10

Windows® 8.1

Windows® 7 SP1

Windows Vista®*1 SP2

*1 Starter edition is not supported.

[Other system requirements]

- Hard disk space: 300MB or more
- RAM: 512MB or more

* Please close all other application software before updating the system software .

【 Mac OS 】

[Supported OS]

Mac OS X v.10.8 – 10.11

macOS v.10.12

[Other system requirements]

- CPU: Intel processor

* Core Solo and Core Duo processors are no longer supported.

- Hard disk space: 300MB or more
- RAM: 512MB or more

* Please close all other application software before updating the system software .



Other items

Power source for the camera

“HXR-NX3”

- AC-L100C(supplied)
- AC-VL1(optional) / DK-415(optional)

“HXR-NX3/1”

- AC-L100C(optional)
- AC-VL1(supplied) / DK-415(supplied)

Note: The update can be performed only when using AC adaptor. Battery cannot use for this update.

USB cable(optional) Type A Male to Mini-B Male Cable

“HXR-NX3” and “HXR-NX3/1” System software update

Windows

For Windows



- When performing the system software update, please use the supplied AC adaptor. update doesn't work in case using battery.
- Do not remove the AC adaptor during the update; otherwise, the camera may become inoperable due to the sudden power shutdown.
- Remove the memory card / memory recording unit from the camera beforehand.

1. Download the update file

Please save the downloaded file onto the Desktop of your computer (recommended).




Update_HXRN3V210.exe

【 File size : 54.9 MB (57,659,120 bytes) 】

For Windows 8.1 /10 users;
Under the initial settings of Internet Explorer, the update file will be saved in the [Downloads] folder. Click the [Desktop] tile from the Start screen and find the downloaded file in the [Downloads] folder by using Explorer.

2. Start up Firmware Updater

- * Please close all other application software before updating the system software .
- Double-click downloaded file to start up Firmware Updater



3. Connect the camera to the computer

1. Camera power on by AC adapter.

Note: Never power off until finish the upgrading.

2. Connect the camera to the computer with the USB cable.




3. Select on the camera screen.

4. After confirm “Mass Storage Connected” is displayed on the camera screen, click the [Next] button on Firmware Updater.

※If the USB CONNECT screen dose not appear, please try the following methods.



* Disconnect the USB cable from the camera, then reconnect the USB cable.

* If there are another USB terminal with the computer, reconnect the USB cable to another USB terminal.




4. Check if the update is required

1. Click the [Next] button to check version.
2. After confirming the current version on the screen, click the [Next] button.



Current version Ver.1.00/1.01/1.02/1.03/2.00 is a target version.


5. Reset the camera

1. Click  on the task tray at the lower right corner of the computer screen to stop the USB connection.

Note: Please keep the USB cable connected even after stopping the USB connection on the computer with the above operation.

2. Touch [OK] on LCD to reset camera body, after then Click the [NEXT] button.



Note: Don't push [RESET] button on the camera, please proceed to the next step.



6. Start the update

1. After resetting, reconnection of the camera is verified, and the “Run the update” screen appears.
2. Click the [Run] button to start the update.
The progress bar appears while updating (approximately 5 minutes).


Note: Never turn off the camera nor disconnect the USB cable while upgrading.



7. Complete the update

1. When the update is completed, the “Finish the update” screen appears. Click the [Finish] button and disconnect the USB cable.




Note: After finished the update, turn off the camera, remove the AC adaptor, and then turn on the camera again.



8. Check the system software version

Follow the instruction below to confirm the system software version is Ver.2.10.

Select [Menu] → [OTHERS] → [VERSION DISPLAY] on the camera.
The system software version is displayed.



END

“HXR-NX3” and “HXR-NX3/1”
System software update

Mac

For Mac OS



- When performing the system software update, please use the supplied AC adaptor. update doesn't work in case using battery.
- Do not remove the AC adaptor during the update; otherwise, the camera may become inoperable due to the sudden power shutdown.
- Remove the memory card / memory recording unit from the camera beforehand.

1. Download the update file

Please save the downloaded file onto the Desktop of your computer (recommended).




Update_HXRNX3V210.dmg
[File size : 62.6MB (65,648,279 bytes)]


2. Start up Firmware Updater

* Please close all other application software before updating the system software .

1. Double-click the downloaded file [Update_NXCAMNX3V210.dmg].
Do not connect the camera yet at this point.
2. [Update_NXCAMNX3V210] icon appears on the Desktop.
3. Double-click the [Firmware Updater] icon.
4. To load a kernel extension, the message prompts you to allow the application to make changes. Type the password for the administrative account.



5. Firmware Updater starts up.




3. Connect the camera to the computer

Remove the memory card from the camera beforehand.




1. Camera power on by AC adapter.

Note: Never power off until finish the upgrading.

2. Connect the camera to the computer with the USB cable.
3. Select  on the camera screen.
4. After confirm 「Mass storage Connected」 is displayed on the camera screen, click the [Next] button on Firmware Updater.


※If the USB CONNECT screen dose not appear, please try the following methods.

- * Disconnect the USB cable from the camera, then reconnect the USB cable.
- * If there are another USB terminal with the computer, reconnect the USB cable to another USB terminal.



4. Check if the update is required

1. Click the [Next] button to check version.
2. After confirming the current version on the screen, click the [Next] button.




Current version Ver.1.00 ~ Ver.2.00
is a target version.

5. Reset the camera



1. Press [OK] on the screen of camera.
2. Click the [Next] button on Firmware Updater.

Note: Don't press [RESET] button on the camera.



6. Start the update


1. After resetting, reconnection of the camera is verified, and “Run the update” screen appears.
2. Click the [Run] button to start the update.
The progress bar appears while updating (approximately 5 minutes).



Note: Never turn off the camera nor disconnect the USB cable while updating.

7. Complete the update

1. When the update is completed, “Finish the update” screen appears. Click the [Finish] button.






2. Disconnect the USB cable.

Note: After finished the update, turn off the camera, and then turn on the camera again.

8. Check the System software version

Follow the instruction below to confirm the system software version is Ver.2.10.

Select [Menu] → [OTHERS] → [VERSION DISPLAY] on the camera.
The system software version is displayed.



END